

# AT11004

## Installation Instructions

1988-1998 Chevy C/K Pickup Standard Cab  
1988-1998 GMC C/K Pickup Standard Cab

1. Before installing, review the installation instructions carefully. Be sure you have all hardware shown in the diagram. (You may have some extra hardware)
2. Locate the body mounts located under the cab behind the inner wall of the rocker panel.
3. Locate front and rear brackets.
4. Remove the front body mount bolt and discard. Be sure to keep the rubber bushing.
5. Using a long bolt, lock washer and flat washer install the front bracket and rubber bushing. Leave the bolt loose for now.
6. Repeat steps 4 and 5 for the rear bracket.
7. Identify the driver and passenger side step tubes. Install a M14 bolt with lock washer and flat washer through the bracket into the front end of tube.
8. Install a M14 bolt with lock washer and flat washer through the rear bracket hole that allows the best appearance into the rear end of tube. Tighten the bolt.
9. Tighten the front M14 bolt holding the tube to the bracket first. Then, tighten the body mount bolts.
10. Repeat the steps above on the other side.